

PWB

Fuji Signal Converter

Dimension


PWBDC
PWBHS
PWBPT

PWBTG
PWBRV
PWBPM

PWBSP
PWBAS
PWBDY

PWBAU
PWBAC

[Unit: mm]



PWBTC

[Unit: mm]

Panel Mounting Dimension

[Unit: mm]

