

CB series Lineup



Black

White



Easy-to-Use



Changing a set point value is as easy as 1,2,3...

Step 1



Press SET key to enable set point changes

Step 2



Change the set point value by using the R/S, and up/down arrow keys.

Step 3



Press the SET key to confirm the new set point.